

## 选择及钥匙开关 Selector&Key Switches

名称外观 Appearance	产品型号 Model	触点形式 Contact Type	操作类别 Operation Type	位数 Positions	颜色 Color	额定电压 Rated Voltage
-----------------	------------	-------------------	---------------------	--------------	----------	--------------------

### 选择开关(常规触点) Selector Switches(Conventional Contact)

	SD30-4110-2	1NO	自锁 Maintained	L R 2P		
	SD30-4101-2	1NC				
	SD30-4120-2	2NO				
	SD30-4102-2	2NC				
	SD30-4111-2	1NO+1NC	自锁 Maintained	L R 3P		
	SD30-5120-3	2NO				
	SD30-5102-3	2NC				
	SD30-5111-3	1NO+1NC				

### 带灯选择开关(常规触点) Illuminated Selector Switches(Conventional Contact)


	SD30-4710-2	1NO	自锁 Maintained	L R 2P	<b>G</b> 绿色 Green <b>R</b> 红色 Red <b>B</b> 蓝色 Blue <b>W</b> 白色 White <b>Y</b> 黄色 Yellow	<b>D</b> 24VDC <b>E</b> 12VDC <b>F</b> 6.3VDC <b>A1</b> 110VAC <b>A2</b> 220VAC
	SD30-4701-2	1NC				
	SD30-4720-2	2NO				
	SD30-4702-2	2NC				
	SD30-4711-2	1NO+1NC	自锁 Maintained	L R 3P		
	SD30-5720-3	2NO				
	SD30-5702-3	2NC				
	SD30-5711-3	1NO+1NC				

### 钥匙开关(常规触点) Key Switches(Conventional Contact)


	SD30-6110-2	1NO	自锁 Maintained	L R 2P		
	SD30-6101-2	1NC				
	SD30-6120-2	2NO				
	SD30-6102-2	2NC				
	SD30-6111-2	1NO+1NC	自锁 Maintained	L R 3P		
	SD30-7120-3	2NO				
	SD30-7102-3	2NC				
	SD30-7111-3	1NO+1NC				

## 外形尺寸 Dimensions

(单位unit: mm)



常规触点选择开关 Conventional Contact Selection Switches



常规触点钥匙开关 Conventional Contact Key Switches